

## KONIG & MEYER 14300 SAXOPHONE STAND BLACK

**22,30 € tax included**

Reference: KM14300



KONIG & MEYER 14300 SAXOPHONE STAND BLACK

Adjustable folding stand for Eb Alto and Bb Tenor Sax. Fiberglass reinforced plastic base. Flexible upper support arm for different bell sizes. Lower support arm bracket with several vertical locking positions. All instrument support parts covered with exclusive non-marring plastic coating. To be used with peg holder 14301 and clarinet peg or with peg holder, adapter 15281 and pegs for trumpet, soprano sax or flugelhorn.

### Data:

- Height: 485 mm
- Instrument support: non-marring plastic material
- Leg construction: socket with foldable legs
- Material: steel
- Special features: fiberglass reinforced plastic base' flexible upper support arm' lower support arm bracket with several vertical locking positions
- Suitable for: Eb Alto and Bb Tenor Sax
- Type: black
- Weight: 1.04 kg