

## PEAVEY MIDI DIRECTOR



**35,00 € tax included**

Reference: UPEMD

PEAVEY MIDI DIRECTOR SEND MIDI PROGRAM CHANGE

### PEAVEY MIDI DIRECTOR SEND MIDI PROGRAM CHANGE

Cambio programmi via midi

Tastiera numerica da 0 a 9

Tasto PRESET

Tasto CHAN

Tasti SONG - START - STOP

Interruttore : Power ON/OFF

Connettore MIDI OUT

Funziona con pila 9V oppure con PSU +9VDC esterno ( NON INCLUSI )